

User Manual ► FEISOL CT-3441S, CT-3441SB and CT-3441T**A. Center Column Operation**

To extend the pre-installed Center Column upward, please unlock the twistlock located just above the mainframe (see picture) by turning it half a turn in counterclockwise direction. After the Center Column is extended to the desired height, turn the twistlock in clockwise direction to securely lock the column into place.



For additional extension (CT-3441S and CT-3441SB only) there is a telescopic second Center Column Section which can be released by turning the top twistlock located just below the top of the lower Center Column Section (see picture) a half turn in counterclockwise direction, extending, and securely re-locking the twistlock. Please do not over-tighten.



B. Leg Tension Adjustment

Insert the two hexagonal wrenches (included) into the two screws at the base of the leg (see picture) and tighten or loosen them to the desired friction, by turning the wrenches in opposite directions.



C. Leg Extension

In order to extend a leg section, turn the twist-lock approximately one half turn in counterclockwise direction. Note: If the twistlock is turned too far, the leg section may fall out and compression rings may become lost or damaged.

To firmly lock a leg section into place, turn the twist-lock approximately one half turn in clockwise direction. Please do not over-tighten.



D. Weight Hook Installation

To increase tripod stability during windy conditions a Weight Hook is included, allowing for heavier objects (backpack, weight bags) to be attached to the tripod. The hook can be screwed onto the bottom plate of the pre-installed Center Column (see picture).



E. Ball-Head (optional) Installation

Making sure that the Center Column is securely locked, screw the Ball-Head onto the mounting screw by turning the Ball-Head clockwise (see picture). Please do not over-tighten.

Note: CT-3441SB models have a Ball-Head pre-installed already.



F. Spike (optional) Installation

Remove the rubber caps on the end of the legs by twisting and working them forward – they fit snugly in order to prevent them from coming off accidentally. After they are removed, a thread is exposed at the tip of the leg, into which a long or short spike can be screwed (for use on scratch- sensitive surfaces, remove spike and replace rubber cap).



G. Short Center Column (optional) Installation

For exchanging Center Columns on the tripod, unscrew the plate at the bottom of the Center Column by turning it counterclockwise (see picture). Next, unlock the twistlock of the Center Column by turning it one turn in counterclockwise direction, and pull the Center Column out of its mount. After unscrewing the bottom plate of the Short Column to be installed, slide the Column into the mount and replace the bottom plate.



Please note that damage to your tripod's Carbon Tubes or Aluminum parts can occur when they dropped, squeezed, overloaded, or forced downward (eg. into sand dunes or snowbanks). Please exercise care to avoid such conditions.